

INSTALLING EDGING

Whilst StoneFlair's edging range can be laid directly into the ground, for stability a more permanent method of fixing is recommended. This may be achieved by digging out a small foundation trench to the required length, approximately 100mm deep and 150mm wide. Fill and level with a foundation mix of 4 parts coarse aggregate to 2 parts building sand to 1 part cement.

Once the foundations have cured, bed the edging by gently tapping the top edge with a rubber mallet into a mortar bed of 4 parts building sand to 1 part cement, ensuring each unit is aligned and level. Back fill the reverse face of the edging with the same mortar mix "haunched" with a 45 degree wedge of mortar to a height that will be concealed by the finished surface.



Photography

Left

Scalloped edging in Cotswold Buff with Yorkvale paving in Autumn Brown

Bottom

Rough Hewn Double Rope Top edging in Antique Red

Stonelap edging in Antique Gold

Purestone Sandstone Rope Top edging in Desert Sand

